

# **FAP A4 SERIES**

In line medium pressure filters

Inline filters with coupled spin-on cartridges, specifically designed for hydraulic applications. Operating pressure up to 24 bar, flow rate up to 500 l/min.

The indicator ports allow to fit a visual electrical differential indicator and an absolute clock manometer or pressure switch.


Sampling port, for fluid contamination analysis, available and easily accessible on the filter head.



HOUSING	tested according to NFPA T3.10.17, ISO12829, ISO3968		
PRESSURE:	Max operating: 24 bar Burst: 55 bar		
CONNECTION:	G 1 1/4" and 1 1/2" SAE 3000		
MATERIALS:	Head: aluminium alloy Bowl: painted steel Seal: NBR (FKM on request)		
BYPASS VALVE:	No bypass 3,5 bar setting		
ELEMENT	tested according to ISO 11170, 2941, 2942, 2943, 3724, 3968,16889, 16908, 23181		
FILTER MEDIA:	Inorganic microfiber: G03 - G06 - G10 - G15 G25 - G40 Paper: C10 - C25		
COLLAPSE PRESSURE:	12 bar		
TEMPERATURE RANGE:	with NBR seal is from -30 °C to +100 °C		
	with FKM seal (OPTION) is from -25 °C to +120 °C		
FLUID COMPATIBILITY:	Full with HH-HL-HM-HV HETG-HEES (acc. to ISO 6743/4). For use with other fluid please contact Filtrec Customer Service (info@filtrec.it).		




# **OVERALL DIMENSIONS**



## **NOMINAL SIZE**

CODE	Н	H1	WEIGHT
FAPA4-21	388	295	9,2 Kg
FAPA4-22	452	358	10,3 Kg





# **ORDERING INFORMATION**

	1.	2.	3.	4.	5.	6.	7.	8.	9.	10.	11.
	FAP	<b>A</b> 4	21	G10	В	B6F7M	0	Z	000	S	0
SPARE	ELEMENT	<b>A</b> 4	21	G10							
1. FILT	ER SERIES			FAP							
2. FILT	ER ELEMEN	T SERIES		A4							
2 5117	ER SIZE										
J. FILI	ER JIZE			21-22					_		
4. FILT	ER MEDIA			000		element			_		
				G03		sfiber $\beta_{5\mu m(c)}$			_		
				G06		sfiber $\beta_{7\mu m(c)}$			_		
				G10		sfiber $\beta_{12\mu m}$			-		
				G15		sfiber $\beta_{17\mu m}$			-		
				G25		sfiber $\beta_{22\mu m}$			-		
				G40		sfiber B <sub>35µm</sub>	. ,	00	-		
				C10		lose B <sub>10µm(c</sub>			-		
				C25	cellu	lose B <sub>25µm(c</sub>	≥ 2		-		
5. SEA	LS			*В	NBR	R			-		
*omitted	for spare eler	ment		V	FK <i>I</i> ∕∕	1			_		
6. COI	NNECTION	IS	]	B6F7M	G 1	1/4" + 1 1/2	?" SAE 300	0 FLANGE	_		
7. BYP	ASS VALVE			0	no k	oypass			-		
Inbuilt in	nto the filter he	ad		D	3,5	bar			_		
8. IND	ICATOR PC	ORT OPTIC	DN	Z		s for absolu cator all plu				ential clog	ging
9. COI	MPULSORY	FIELD		000	_	ec standard		• 	-		
10. CC	ORROSION	PROTECT	ION	S	stan	idard (filter h	ead with no	treatment)	-		
11. OF	PTIONS			0	no d	option			-		

## ACCESSORIES

The accessories must be ordered separately

INDICATOR	MPO	pressure gauge rear connection, scale 0-16 bar
(Y and F) digit for FKM seal option	MPC	pressure gauge rear connection, setting 3 bar, scale 0-10 bar
For other options see clogging indicators catalogue	MRC	pressure gauge radial connection, setting 3 bar, scale 0-10 bar
	EX2 (EY2)	differential electric 2,7 bar
	VX2 (VY2)	differential visual 2,7 bar
	VEXF2	differential visual electric 2,7 bar
	PO1 (PF1)	metal plug for indicator seat
ACCESSORIES	PF4NF6F7M	FKM flange kit
	FMSA08S0	sampling point - check coupling M16x2 with G"1/4 connection thread
	FMSA09S0	microhose for check coupling M16x2 – length 1m




## PRESSURE DROP (Ap) INFORMATION FOR FILTER SIZING

The total Delta P through a filter assembly is given from Housing  $\Delta p$  + Element  $\Delta p$ . This ideally should not exceed 1,0 bar and should never exceed 1/3 of the set value of the by-pass valve. N.B. All the reported data have been obtained at our laboratory, according to specification ISO3968 with mineral oil having 32 cSt viscosity and density 0,875 Kg/dm<sup>3</sup>.

### HOUSING PRESSURE DROP

The housing  $\Delta p$  is given by the curve of the considered model and port, in correspondence of the flow rate value.



### **ELEMENT PRESSURE DROP**

The element  $\Delta p$  (bar) is given by the flow rate (l/min) multiplied by the factor in the table here below correspon-ding to the selected media and divided by 1000. If the oil has a viscosity Vx different than 32 cSt a corrective factor Vx/32 must be applied.

Example: 200 l/min with A421G10 and oil viscosity 46 cSt:200 x (0,88/1000) x (46/32) = 0,25bar

	G03	G06	G10	G15	G25	G40	C10	C25
A421	1,82	1,45	0,88	0,55	0,40	0,20	0,30	0,25
A422	0,68	0,54	0,37	0,35	0,33	0,14	0,21	0,14

### **EXAMPLE OF TOTAL** $\Delta p$ CALCULATION

FAPA421G10BB6F7M0Z000S0 with 200 l/min and oil 46 cSt (using G 1  $\frac{1}{4''}$  threaded port) Housing  $\Delta p$  0,12 bar + element Dp 0,25 bar (200 x 0,88/1000 x 46/32) = total assembly  $\Delta p$  0,37 bar



# ACCESSORIES

These accessories must be ordered separately.



04.006.00539	FMSA08S0	sampling point - check coupling M16x2 with G 1/4 connection thread
		MT0X2 with G 1/4 connection miedu

Allows you to control the pressure safely while the system is at full capacity and can be used to obtain fluid samples.



04.006.00538 <b>FMSA09S0</b> microhose for check coupling M16x2 – length 1m	
---	--

Allows to connect the check coupling to the microhose by screwing them together by hand, without the use of special tools and without the risk of leaks while the system is in operation. The connection is automatically sealed and does not become loose as a result of vibration or pressure surges.



07 036 00109	PF4NF6F7M	FKM flange kit
07.000.00107		I INN HUNGE KI

Flange to switch from 1 1/2" SAE 3000 connection to 1 1/2" NPTF. The kit includes 1 flange, 1 o-ring, 4 screws and 4 washers.



# **USER TIPS**



- 4 FILTER CARTRIDGES
- 5 SAMPLING PLUG PORT

### **CARTRIDGE TIGHTENING TORQUE**

All models

1/2 turn

### INDICATOR TIGHTENING TORQUE

Differential	50 Nm
Absolute	10 Nm

### WARNING

Make sure that Personal Protective Equipment (PPE) is worn during installation and maintenance operation.

## DISPOSAL OF FILTER ELEMENT

The used filter elements and the filter parts dirty of oil are classified as "Dangerous waste material": they must be disposed according to the local laws by authorized Companies.

### **INSTALLATION**

- 1. The IN and OUT ports must be connected to the hoses in the correct flow direction an arrow shows on the filter head (1).
  - The filter housing should be preferably mounted with the cartridge (4) downward.
  - 3. Secure to the frame the filter head (1) using the threaded fixing holes (3).
  - 4. Verify that no tension is present on the filter after mounting.
  - 5. Enough space must be available for filter element cartridge replacement.
  - 6. The visual clogging indicator must be in an easily viewable position.
  - 7. When an electrical indicator is used, make sure that it is properly wired.
- 8. Never run the system with no filter element fitted.
  - 9. Keep in stock a spare FILTREC filter element for timely replacement when required.
  - 10. Filter housing should be earthed.

### **OPERATION**

1. The filter must work within the operating conditions of pressure, temperature and compatibility given in the first page of this data sheet.

- 2. The filter element must be replaced as soon as the clogging indicator signals at working temperature (in cold start conditions, fluid temperature lower than 30°C, a false alarm can be given due to oil viscosity).
- 3. If no clogging indicator is mounted, replace the element according to the system manufacturer's recommendations.

#### MAINTENANCE

- 1. Make sure that the system is switched off and there is no residual pressure in the filter.
  - Unscrew the filter cartridges (4) by turning them anti-clockwise and remove them. Check the condition of the gaskets located at the end of the threated spigots; replace them if necessary.
  - 3. Fit new FILTREC cartridge elements (4), verifying the part number, particularly concerning the micron rating.
- <u>4</u>.
- Ensure that the head mounting face is clean.
  Lubricate the gaskets of the replacement cartridges and the threads prior to assembly.
  - Spin on the new cartridges until they reach the mounting face and tighten for 1/2 turn.





CT140-04/25

www.filtrec.com