

FA4 SERIES

Tank-top, spin-on type filters



USER TIPS



- 1 FILTER HEAD
- 2 INDICATOR PORT
- 3 FIXING HOLES
- 4 FILTER ELEMENT



CARTRIDGE TIGHTENING TORQUE

| | |
|------------|----------|
| All models | 3/4 turn |
|------------|----------|

INDICATOR TIGHTENING TORQUE

| | |
|-----------------------|-------|
| Pressure gauge/switch | 10 Nm |
|-----------------------|-------|

WARNING

- Make sure that Personal Protective Equipment (PPE) is worn during installation and maintenance operation.

DISPOSAL OF FILTER ELEMENT

- The used filter elements and the filter parts dirty of oil are classified as "Dangerous waste material": they must be disposed according to the local laws by authorized Companies.

INSTALLATION

- 1. Secure the filter head (1) on the tank lid through the fixing holes (3).
- 2. Connect the hose to the IN port and verify that the OUT port is clear.
- 3. Verify that no tension is present on the filter after mounting.
- 4. Enough space must be available for filter element cartridge replacement.
- 5. The visual clogging indicator must be in a easily viewable position.
- 6. When a electrical indicator is used, make sure that it is properly wired.
- 7. Never run the system with no filter element fitted.
- 8. Keep in stock a spare FILTREC filter element for timely replacement when required.

OPERATION

- 1. The filter must work within the operating conditions of pressure, temperature and compatibility given in the first page of this data sheet.
- 2. The filter element must be replaced as soon as the clogging indicator signals at working temperature (in cold start conditions, oil temperature lower than 30°C, a false alarm can be given due to oil viscosity).
- 3. If no clogging indicator is mounted, replace the element according to the system manufacturer's recommendations.

MAINTENANCE

- 1. Make sure that the system is switched off and there is no residual pressure in the filter.
- 2. Unscrew the filter cartridge (4) by turning it anti-clockwise and remove it.
- 3. Fit a new FILTREC cartridge element (4), verifying the part number, particularly concerning the micron rating.
- 4. Ensure that the head mounting face is clean.
- 5. Lubricate the gasket of the replacement cartridge and the thread prior to assembly.
- 7. Spin on the new cartridge until it reaches the mounting face and tighten for 3/4 turn.